

ANKER

Live Charged.

For tutorial videos, FAQs, manuals, and more information, please visit:

<https://support.anker.com>

Or scan the QR code below:



@anker_official
@anker_jp



@AnkerDeutschland
@AnkerJapan
@Anker



@AnkerOfficial
@Anker_JP




USER GUIDE

取扱説明書はこちら | 用户指南




PAP 22
Raccolta Carta

Product Number: A1636
5100500XXXX V01



Anker Power Bank
(30W, Fusion, Built-In USB-C Cable)

QUICK START GUIDE



Important Safety Instructions

When using this product, basic precautions should always be followed:

1. Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or personal injury.
2. Operating temperature should be between 0°C to 35°C / 32°F to 95°F.
3. Do not disassemble this product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or personal injury.
4. CAUTION: Risk of explosion if the battery is replaced by an incorrect type.
5. To reduce the risk of injury, close supervision is necessary when the product is used near children.
6. Do not expose power bank to rain or snow.
7. Do not use the power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperature above 100°C may cause explosion.
Switch off the power bank when not in use.
9. CAUTION: Risk of Fire and Burns. Do Not Open, Crush or Incinerate. Follow Manufacturer's Instructions.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur

in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- (1) Reorient or relocate the receiving antenna.
- (2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the receiver

is connected.

(4) Consult the dealer or an experienced radio / TV technician for help.

The following importer is the responsible party (for FCC matters only).

Company Name: Fantasia Trading LLC

Address: 5350 Ontario Mills Pkwy, Suite 100, Ontario, CA 91764

Telephone: +1 800 988 7973

IC Statement

This digital apparatus complies with CAN ICES-003(B)/NMB-003(B).

Déclaration IC

Cet appareil numérique est conforme aux normes CAN ICES-003(B)/NMB-003(B).

Declaration of Conformity

Hereby, Anker Innovations Limited declares that this product is in compliance with Directives

2014/35/EU, 2014/30/EU & 2011/65/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://www.anker.com>.



This symbol indicates that this product shall not be treated as household waste. Instead, it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

The following importers are the responsible parties (contract for EU and UK matters)

Anker Innovations Deutschland GmbH

Georg-Mueller-Strasse 3, 80807 Munich, Germany

Anker Technology (UK) Ltd

GNR8, 49 Clarendon Road, Watford, Hertfordshire, WD17 1HP, United Kingdom

安全にご使用いただくために

本製品を使用する際には、下記の注意事項をお守りください。

1. 製造元により販売もしくは推奨されていない製品（充電器など）を使用した場合、火事や怪我につながる恐れがあります。
2. 動作温度は約 0°C ~ 35°C です。
3. 危険ですので分解しないでください。故障だと思われる場合は、カスタマーサポートまでご連絡ください。分解後、誤って組み立てると火事や怪我につながる恐れがあります。
4. 注意：破損したまたは改造されたバッテリーは、火事・爆発・怪我を引き起こす危険性があります。
5. 事故を防ぐため、お子様の手の届かないところでご使用ください。
6. 雨や雪にさらさないでください。
7. 危険ですので、分解しないでください。修理が必要な場合は、カスタマーサポー

トまでご連絡ください。分解したり誤って組み立てると、火事や怪我につながる恐れがあります。

- 高温にさらさないでください。火や 100°C を超える温度にさらされると、爆発を引き起こす恐れがあります。
- ご使用にならない場合は、本製品の電源をオフにしてください。
- 本製品を分解しないでください。不具合が発生している場合は、カスタマーサポートまでご連絡ください。分解中または分解後に誤って組み立てる際に火災や怪我につながる恐れがあります。



本製品を廃棄する際は、お住まいの自治体のルールに従ってください。

筒中

重要安全说明

使用本产品时，应始终遵循基本预防措施：

- 使用非产品制造商推荐或销售的电源或充电器可能会导致火灾或人身伤害风险。
- 操作温度应在 0° C 至 35° C / 32° F 至 95° F 之间。
- 请勿拆卸此产品。当需要维修或修理时，请将其送到合格的服务人员那里。错误的重新组装可能导致火灾或人身伤害风险。
- 注意：如果更换了不正确的电池类型，可能会发生爆炸的风险。
- 为了降低受伤风险，在儿童附近使用该产品时需要进行密切监督。
- 不要将移动电源暴露在雨雪中。
- 不要使用已经损坏或修改过的移动电源。损坏或修改过的电池可能会表现出不可预测的行为，导致火灾、爆炸或受伤的风险。
- 不要将电源包暴露在火源或过高温下。接触火源或温度高于 100° C 可能会导致爆炸。
- 不使用时，请关闭移动电源。
- 注意：火灾和烧伤风险。请勿打开、碾压或焚烧。遵循制造商的说明。
- 使用过程中，产品温度略高于常温，属正常现象，建议与产品的接触时间小于 10 秒。
- 浸水后禁止使用。



此符号表明本产品不得作为生活垃圾处理，相反，应将其交付给适用的收集点进行电子设备回收。



仅适用于海拔2000m以下地区安全使用



support@anker.com

support.me@anker.com (For Middle East and Africa Only)

(US/CA) +1 (800) 988 7973

(UK) +44 (0) 1604 936200

(DE) +49 (0) 69 9579 7960

(Middle East & Africa) +971 529 750 842

(UAE) +971 8000320817

(KSA) +966 8008500030

(Kuwait) +965 22069086

(Egypt) +20 8000000826

(AU) +61 3 8331 4800

(TR) +90 0850 460 14 14

(RU) +8 (800) 511-86-23

(India) +91 18003138831

(中国) +86 400 0550 036

(日本) 03 4455 7823

(한국) +82 02-1661-9246

